

School Pad/Mobi and Interwrite Workspace Beginners Manual

elnstruction Support: 480-443-2214

www.einstruction.com



Join the elnstruction Community to connect with other educators, find free high-quality resources, and learn about the latest best practices and technologies in classroom instruction. Resources are searchable to make finding what you need fast and simple. Plus, check out blogs and discussion boards to find out what other education professionals are talking about.

Register Today at: www.eicommunity.com



School Pad/Mobi and Interwrite Workspace Beginners Manual

What is Workspace?2	Annotation Tools
Getting Started2	Editing Tools9
Charging the Interwrite Pad2	Selection Tool Properties10
Charging the Interwrite Mobi2	Extending a Page and Panning11
Charging the Interactive Pens2	Layers Toolbar11
Connecting the Interwrite Panel3	File Management Tools12
Installation of Software3	Presentation Tools13
Setup and Device Manager3	Copy and Paste14
Connecting Bluetooth Devices3	The Gallery14
Connecting RF Devices4	Categories14
KWIK Screen on the Mobi4	Resources from Gallery14
Naming Devices5	Searching for Resources15
Calibrating Devices5	Sample Lessons15
The Interactive Pen5	Add Media from File15
Interactive Mode6	Add Media from Selection16
The Basic Toolbar6	Remove Media from Gallery16
Moving the Toolbar6	Multi-User16
Resizing the Toolbar6	Setting Up Multi-User16
Toolbar Settings6	Set Presenter17
Creating Pages7	Locking Pads17
Blank Pages7	Creating New Lessons17
Grid Pages7	The Toolbox18
Main Tools and Descriptions8	

What is Workspace?

- Workspace is a program that connects a computer to an Interwrite interactive whiteboard, panel or wireless pad.
- The program includes tools for writing and drawing during a presentation.
- Teachers can use Workspace to create and conduct interactive lessons.







Interactive Pad



Interactive Mobi



Interactive Whiteboard

Getting Started

- Before using the Interwrite Pad, Interwrite Mobi, or the interactive pen for the first time, they should be charged for about 12 hours.
- Make sure Pad and Pen(s) are charged before connecting to the computer.

Charging the Interwrite Pad

- Plug the AC adapter into the top of the pad and then into a power source.
 Note: The Interwrite Pad can be used while it is charging.
- · Secure the pen in the recharging holder.
- · Two orange lights will appear indicating the Pad's battery and pen.
- Lights turn off once the Pad and/or pen are fully charged.

13

Charging the Interwrite Mobi

- . When the Mobi battery is low, the Battery Status icon will display as an empty battery.
- Place the Interactive Pen in the Pen slot.
- Connect the Mini USB Cable to the Mini USB port at the top of the Mobi and then into a USB port on the computer. Note: The Interwrite Mobi can be used while it is charging.
- When fully charged the Battery Status icon will display a full battery.
- Unplug the charging cable from the Mobi.

-/

Charging the Interactive Pens

- Plug in the AC adapter for the Interwrite Board.
- Make sure the charging pen holder is plugged into the control box on the board.
- Secure the pens into the holder.
- · Green lights will appear for each pen.
- Lights turn off once the pens are fully charged.
- Note: extra pen tips can be stored on the charging pen holder.






Connecting the Interwrite Panel

- Plug in the AC adapter for the Panel.
- Connect the USB cable and the VGA cable to the computer.



Installation of Software

- . Install Interwrite Workspace using the CD that came with the interactive Panel, Board or Pad.
- Workspace may also be downloaded from http://www.einstruction.com/support_downloads/downloads.html.
- For wireless pads and wireless whiteboards:
 - Plug in the USB Bluetooth Receiver.



- After a minute the wizard will indicate that the drivers are found and the device is ready to use.
- Note: Take notice of the USB port in which the Bluetooth Receiver is installed. If the receiver is
 plugged into a different USB port another time, the Hardware Wizard will reappear indicating a
 new device has been detected again as noted in the steps above.
- Once the software and Bluetooth Receiver have been installed, restart the computer. Two new icons will display in the System Tool tray on the bottom right of the screen.



Setup and Device Manager

Connecting Bluetooth Devices

The Interwrite Board and the Interwrite Pad connect to the computer wirelessly using a USB Bluetooth connection. The Interwrite Panel connects directly through a USB cable. **Note:** If there is **not** an internal Bluetooth in the computer, make sure that the Bluetooth "dongle" is connected and installed on the computer.

- Turn on the Board or Pad. A series of beeps will sound. For the panel, make sure the power is turned on.
- Click on the elnstruction Tools icon.
- Select einstruction Device Manager.
- Close the Device Manager First Look Window after reading the top section to find the Bluetooth address. Note: Uncheck the box at the bottom of this window to not show the First Look Window at start up.
- Click on the green plus button to add a Bluetooth



File Options Help

- device and/or the panel.
- Type in the last four digit or letter combination of the Bluetooth address and click Connect.
- Or click on Scan for Devices. Wait for the scan to finish.
- Once the scan finds the device, select the device and click Connect.
- The device manager will connect the device and then display the device icon in the einstruction Device Manager window.
- The pad or board will beep when connected.

Connecting RF Devices

The Interwrite Mobi and the Interwrite DualBoard connect to the computer wirelessly using an RF (Radio Frequency) communication module.

- Plug the RF Receiver into a USB port on the computer. The computer will automatically detect
 the USB device and install the new hardware for use.
- A blue LED light on the RF Receiver will light up when it is plugged in.
- · Turn on the Mobi or DualBoard.
- Press the lighted Activation button on the RF Receiver. The blue LED light will start blinking.
- Turn over the Mobi and press the blue button next to the battery case to activate the RF signal. Note: Up to two minutes is allowed to press the Activation button on the Mobi or DualBoard.
- When paired, the blue LED light on the RF Receiver will stop blinking and remain solid blue until either the computer or the Mobi is turned off.
- The Mobi or DualBoard device icon will display in the eInstruction Device Manager window.



And Bluetooth Beyne

Finished Scan

Enter or Choose Bluetooth Address

IVI SP 400 TEC Pad 1 (008098E40FE3)

Connect Scan for Devices Cancel

KWIK Screen on the Mobi

The Mobi KWIK Screen displays icons associated with the Mobi status.

Icon Name I		Description
M	Mouse Mode	Pen used as a mouse
₹	Paired	Paired with computer
Ψ	USB	Connected via USB cable
	In Proximity	Pen within proximity, detected by Mobi
	In Menu	KWIK screen in use, out of proximity
	Battery Status	Battery life and charge shown
297	Pen Charge	Pen charge shown

Naming Devices

- · Select the device icon in the Device Manager window.
- Click on Options and select Properties or click on the
 - wrench Properties button.
- Select the General tab at the top of the window.
- Type a device name in the Name text field.
- Note: This is also where the battery status of the Interwrite pad can be checked.




Calibrating Devices

- · Note: Only Whiteboards and Panels require calibration.
- Select the device from the Device Manager window.
- Click the Options button.
- Select Calibrate.
- A blue screen will appear with instructions.
- Click on each cross-hair target as it appears on the screen.
- The blue screen will disappear after last cross-hair target is clicked.
- The Interactive Whiteboard also features a shortcut softkey on the side of the board for quick calibration.

The Interactive Pen

- Interwrite Boards, Panels, and Pads require an interactive pen.
- Tap on the board, pad or panel with the pen tip to left click.
- Hold pen just above the surface of the board, pad or panel and press the upper part of the button towards the top of the pen to right click.
- Hold pen just above the surface of the board, pad or panel and press the lower part of the button towards the tip of the pen to double click.




- Recharge the pen regularly.
 - Place the pen firmly in the recharging holder.
 - A light will indicate if the pen is charging properly. Note: When charging the Mobi pen, a
 pen and a battery icon will appear on the KWIK screen indicating the pen is charging.
 - o Remember to return the pen to the recharging holder when not in use.

Interactive Mode

- Click on the einstruction Tools icon in the tool tray and select Workspace.
- Interactive mode may also be accessed through the Start menu → All Programs → eInstruction
 → Interwrite Workspace → Interactive Mode.
- A toolbar will appear near the right hand side of the desktop.
- The toolbar will go transparent after non-use.

The Basic Toolbar



Moving the Toolbar

 Position the mouse pointer at the top of the toolbar near the Interwrite icon



 Click and drag the toolbar to new location.

Resizing the Toolbar

- Position the mouse pointer on the edge of the Toolbar until a double-headed arrow appears.
- Click and drag the doubleheaded arrow to change the size and layout of the Toolbar.

Toolbar Settings

- Click on the Workspace
 Menu button and select Preferences.
- Click on the Toolbar Settings tab.
- Under the section Shape Files, select a desired shape. A preview will display.
- Under the section Toolbar Button Size in Pixels, select the desired size.
- Click Ok.


Creating Pages

Tool	Name	Description
	Blank Page Tool	Click to create blank pages for lessons, notes, etc. To change the color of the page: Choose the selection tool Click on the white box located on the property toolbar at the bottom of the screen. Choose color. Click Ok. Note: The color will only change on this page.
	Grid Page Tool	Click to create grid pages for lessons, notes, etc. To change a blank page to a grid page: Click on the grid page tool located on the properties toolbar at the bottom of the screen.

Blank Pages

- To customize the page color:
 - Click on the Workspace Menu button
 - Click on New Page Setup tab at the top of the window.
 - Click on the Change Background Color button.
 - Select a new color as the default page color.
 - Click Ok.
 - Click on the Create Blank Page
 button on the toolbar to create
 a new page in Workspace.

and select Preferences.




Grid Pages

- To customize the grid lines and colors:
 - Click on the Workspace Menu
 button and select

Preferences.

- Click on the New Page Setup tab at the top of the window.
- Make desired changes in the Grid




Page area.

- Click on the Change Background Color button.
- Select a new color as the default grid page color.
- Select other desired changes such as vertical lines, center grid, title box, line color, line spacing, etc.
- Click Ok.
- Click on the Create Grid Page button on the toolbar to create a new grid page in Workspace.

Main Tools and Descriptions

Properties Bar

 When selecting any tool a Properties Bar will appear at the bottom of the screen with options specific to that tool.



Annotation Tools

Tool	Name	Description
1001	Pen Tool	Click to write and/or make notes on the screen or Workspace page. This tool gives the option to change pen color, width, transparency, style, etc. by using the property bar.
	Highlighter	Click to highlight any text or image on the screen or Workspace page. This tool gives the option to change highlighter color, shape, width, transparency, etc. by using the property bar.
	Shapes Tool	Click to create basic shapes. To change to a different shape: Click on the shape in the property bar and select desired shape. Use options on the property bar to modify the shape outline, width, outline style, transparency, shape style, color fill, etc. Click and drag to draw the shape on the screen or Workspace page.

Tool	Name	Description
111:	Line Tool	Click and drag to create lines on the screen or Workspace page. Note: Use the selection tool to select the line and then use the four-headed arrows to change the angle or length of the line. Use the eraser tool to cut the line in parts maintaining the endpoints chosen for the original line.
abc	Text Tool	Click on the text tool then click on the page where the text will be placed and type text into the box that appears. Click on the Duplicate Text button of the text box with the same text. Click on the Split Text button to separate multiple words into their own individual text boxes.

Editing Tools

Tool	Name	Description
	Eraser	Click to erase annotations. Note: the Eraser tool only erases lines drawn with the Pen, Highlighter, and Line tools. It does not work with Shapes, Imported images, or Sims. Change eraser size by clicking and dragging the slider in the Eraser property bar. Use pad Pen to erase by holding the double click button when the Pen tool is in use.
	Undo	Click to Undo or remove the most recent change to a Workspace page. Keep clicking to continue removing changes until there are no more changes to remove.
8	Clear	Click to remove items on a Workspace page. With the Selection tool , select any Item on a page and then click the Clear tool to delete the selected item. If no selection is made the Clear tool will clear all items from a page.

Tool	Name	Description
	Selection Tool	Click to select items on a Workspace page. This tool gives the option to redo, undo, cut, copy, paste, select all, arrange, rotate, group, export, move to background, move to gallery, etc., by using the property bar. Use the selection tool to click on text, lines, shapes or images on a Workspace page. A bounding box will appear around the item selected. Options for that item will appear in the property bar at the bottom of the screen. Select desired options to change previous options. To move, resize, or rotate an item: • Move: Select an item to get the four-headed arrow. Drag item to new location. • Resize: Select an item. Click on the rotate icon at the top center of the selection bounding box and drag box to new size. • Rotate: Select an item. Click on the rotate icon at the top center of the selection bounding box and drag box to new angle. To lock or easily copy multiple copies of an item: • Lock: Select an item. Click on the Lock Tool In this will display a lock icon on the item when it is selected. • Copier: Select an item. Click on the Copier Tool Click and drag as many times as desired to get copies of the item. This will diplay a copier icon on the item when it is selected.

Selection Tool Properties



Tool	Name	Description
13 8 1	Undo/Redo	Click to undo or redo the most recent performed task. Continue to click for undoing or redoing more tasks.
V.	Cut	Click to remove a selected item.
	Сору	Click to copy a selected item.
	Paste	Click to paste a cut or copied item onto a Workspace page.

10	Select All	Click to select all items on a Workspace page.
Euc :	Order Selected	Click to change the position of a selected item to be in front of
7.5	Entities	or in back of other items on the Workspace page.
DES	Rotate Selected	Click to rotate a selected item 90°, 180°, or flip item
(5)	Entities	horizontally or vertically.
Town	Crown	Click to group separate selected items together to create one
- 42	Group	item.
Tella	Ungraum	Click to ungroup a previously grouped item to separate the
10	Ungroup	items.
10	In the second	Click to permanently "glue" an item to the background of a
1787	Move to Background	Workspace page.
D2	Funant Entities	Click to export a selected item and convert it into an image
1 20	Export Entities	file.
184	Add files to Gallery	Click to add a selected item or the entire page to the Gallery.

Extending a Page and Panning

- By clicking on either the downward extend button or the right side extend button this will extend the default blank page space onto the Workspace page.
- Click on the Pan Tool located at the bottom right corner of the screen and then click and drag on the Workspace page to move in any direction across a page that is larger than the current screen size.
- · The cursor will change to a hand.
- Click on the pan tool again to turn off the pan option.

Layers Toolbar

By default, all items are organized in a single layer. To add layers:

- Locate the Layers Toolbar at the bottom left corner of the Workspace page.
- To view the layers click on the maximize layers button
- Click the Add Layer button
- The Layer Toolbar has additional options such as moving layers up/down, selecting layers, showing/hiding layers, editinig layers, and deleting layers.

File Management Tools

Tool	Name	Description
	Workspace Menu	Click to access files, edit, print, change preferences, etc. To Save a File: Click on the Menu button. Select File. Click Save As. Type in a file name. Click Ok. To Open a File: Double click on the file. Click Open. Choose the file to be opened and click OK. To Export a File: Click on the Menu button. Select File. Click on the Menu button. Select File. Click on the Menu button. Select File. Click Export. Choose the format desired for export, the location for export, and the page(s) desired to export. Click Export when done. To Print a File: Click on the Menu button. Select File. Click Print. Click Print. Choose the options for the printer and click Print.
(- ->	Previous/Next Page	Click to navigate backward or forward through already created pages in Workspace. Note: There is an alternative method to navigate pages in the lower right-hand corner of the screen. This method also includes the current page number and page count.

Tool	Name	Description
	Page Sorter	Click to view all Workspace pages. For viewing size, click on the Page Sorter Menu button . Select Zoom and choose desired page size for Page Sorter window. To reorder/rearrange pages: Highlight one or multiple pages by clicking on the page. Drag and Drop to new position. Exit the page sorter window when done. To delete pages: Highlight one or multiple pages by clicking on the page. Click the delete button at the top of the Page Sorter window. Note: Pressing the delete key on the keyboard will also delete selected pages when in the Page Sorter window.
	Save	To Save a file: Click on the Save tool. Select location for the file to be saved. Type a name for the file. Click Ok.
	Toolbox	Click to display a submenu of additional tools. (See page 18)
	Exit	Click to Exit Workspace completely.

Presentation Tools

Tool	Name	Description
	Minimize Toolbar	Click to minimize the Workspace toolbar so it does not block any other program or application.
0	Mouse Mode	Click to return regular functionality to the computer and allow pen to work like a mouse. Use any drawing tool (pen, shape, text, etc.) to instantly record a screen capture and return to Workspace. Click on the navigation arrows to return to a Workspace page.

Tool	Name	Description
	Lesson Mode	Click to return to the default Workspace Toolbar in Interactive Mode.
	Student Response System	Click to use Workspace Interactive Mode with Interwrite products such as PRS transmitters, Response software, etc.

Copy and Paste

- Select the graphic.
- · Right click on top of the picture.
- Select copy.
- Go back to the workspace lesson.
- Paste the graphic on your lesson by clicking the paste button or clicking on Ctrl+V at the same time.

The Gallery

Tool	Name	Description
	Gallery tool	Click to access resources using Interwrite Gallery window.


Categories

- Select different categories to view pre-existing files organized by subject.
- Select subject and sub-categories.
- · Click on resource in the lower window.
- Drag resource to existing page in Workspace.

Resources from Gallery

Image Type	Description	
	Background: The folded corner indicates this image takes	
	the whole screen and it is used as a background on a	
	Workspace page.	
\$	Image: A single image can be resized, moved, or rotated	
	on a Workspace page by using the selection tool and then	
	clicking and dragging the item.	
	Sims: The symbol indicates that this is an interactive	
	program made in Flash that includes animation, sound, or	
2 = 2 =	games. These Sims are provided free with Interwrite	
- 0	Workspace.	
	Note: Many of the Sims do not include instructions and	
	require some playing in order to learn how to use them.	





Searching for Resources

- Type a keyword in the text field at the top of the Gallery window.
- Click on the Keyword Search button
- Scroll through the resources in the lower window to find search matches.

Sample Lessons

- To view sample lessons, select Lessons in the upper Gallery window.
- Online Lessons:
 - Click on the Online Lessons category to go to the elnstruction website online lessons and resources available for download (http://www.einstruction.com/support_downloads/content/workspacelesson/index.html).
 - Search for lessons by viewing all, browsing by state curriculum standard, or by keyword.
 - Click on desired lesson.
 - Click on the Download button.
 - Save download .gwb file to My Documents/Interwrite Workspace/ Lessons.
 - Lessons can be saved, modified, and re-used with changes.

Sample Lessons:

- Click on Sample Lessons to view, open, and edit sample lesson files for Workspace.
- These files are also found in C:\Program Files\Interwrite Learning\Interwrite
 Content\Lessons.

Video Tutorials:

- To view video tutorials, select Video Tutorials to go to the einstruction website online tutorials (http://www.einstruction.com/support_downloads/training.html).
- These tutorials go over basics of using tools in Workspace.

Add Media from File

- Click on the Gallery button
- Click on the Gallery Menu button
- Select Add a File to Gallery.
- Click the Browse button to find media resource.
 - Images: BMP, JPEG, GIF, EMF, WMF, TIFF, PNG, ICO
 - Sound: WAV, MP2, MP3, MPA, MPEG, SND, WMA
 - Video: AVI, WMV, MOV, MPEG
- Click Ok.
- Select or type in a category.
- Type in a Name to be displayed.
- Type in any relevant Keywords describing the resource.
- Click Save and Exit or Save and Add Another.



Add Media from Selection

- Click the Selection tool
- Click to select an item on the current Workspace page.
- Click on the Add Files to Gallery button on the Property bar.
- Select Add Selection to Gallery.
- · Select or type in a category.
- Type in a File Name. (Note: Choose category before naming the file.) Remember to add the file extension .png to the file name.
- Type in a Name to be Displayed.
- Type in any relevant Keywords describing the resource.
- Click Save and Exit.

Remove Media from Gallery

- Right click on the desired resource to be removed in the lower Gallery window.
- Select Remove from Gallery.
- Note: if Delete Permanently is selected, this action cannot be undone and the resource will be removed completely from the Gallery database.

Multi-User

- With the DualBoard interactive whiteboard two people can write on the board at the same time.
- With multiple Pads or Mobis more than one can write on the screen at a time.
- Using a Bluetooth dongle up to seven devices may be connected to the computer at once.
- Using the Multi-User option in the software and RF receivers with the Mobi or DualBoard up to 9
 devices can be writing on the screen at once.

Setting Up Multi-User


- First connect all devices to be used in the Device Manager window.
- Open Interactive Mode and create a blank page.
- Click on the Multi-User icon in the bottom right corner of the screen. Note: The connected devices will be displayed.



- Select Multi-User Page Setup.
- Select the page layout desired.







Multi-User Page Setup

Turn Multi-User off

View Devices

- Select each device and drag it to the area desired.
- Click Ok.
- Each device in the page layout will have its own simplified toolbar.

Set Presenter

- Open the Device Manager window.
- Select the device desired to be the master pad.
- Click on the Options menu.
- Select Set Presenter.
- Click Ok.

Locking Pads

- Open the Device Manager window.
- Select the device to be locked.
- Click on the Lock Pad icon



A lock all/unlock all pads button Lock Pads is also located in the Toolbox on the Workspace Toolbar.

Creating New Lessons

- Click on the Workspace Menu icon
- Select File → New. Note: Launching Workspace software if closed will also begin a new file.
- Add a new blank page or a new grid page from the toolbar.
- Add text to a page using the Text tool
 - Type text into text box.
 - Copy and paste text from existing documents.
 - Resize text box to desired size.
- Add images and sound files from the Gallery
- Add basic shapes to a page using the Shapes tool
- Use the Selection tool and click on any item on the page to move, resize or rotate.
- To make copies of shapes, text, etc.:
 - Select the item.
 - Select the Copier tool







MAAB / U M M M H E

Lesson text goes here.



Navigate lesson pages by using the Previous Page and Next Page tools



Find pages, reorganize or delete pages using the Page Sorter tool



Click on Workspace Menu → File → Save.

The Toolbox

- Click on the Toolbox tool on the toolbar.
- A sub-menu will appear displaying additional tools available in Workspace.
- Below are some of the additional tools with descriptions of the tools that appear in the Toolbox.

Tool	Name	Description
	Annotate over Desktop	Click to use like Mouse Mode, however the desktop is underneath and can be accessed for use without annotations disappearing. Use the selection tool for mouse function. Once another tool is selected, a prompt will ask to save or discard the annotations as a page.
-	Office Mode	Click to integrate tool use with Microsoft Office Programs.
	Exam View	Opens the exam view file.
Sound	Ruler	Use to show measurement between two points interactively.
	Triangle	Use to demonstrate how to measure interactively. Select from left or right facing triangles.
	Protractor	Use to demonstrate how to use angle measurement interactively. Select from 180° or 360° protractors.
A	Compass	Use to draw circles, arcs, and measure distances interactively. Use the selection tool to exit.
*	Curtain	Toggles virtual curtain to partially cover screen in Workspace. The curtain properties bar has resize handles, gives maximize and transparency options, and closes the tool.
16	Capture	Captures items, windows, or screens from computer screen.
	Record and Playback	Opens control to record and display a Workspace lesson.
\$	New Page Setup	Changes default page settings for new blank and grid pages.
2	Stamper	Adds quick shape or image with each mouse click.
8	Fill Tool	Adds quick fill color to image or page with each mouse click.
Pipe	Freehand Text	Converts text written with the interactive pen into text format.
*	Freehand Shape	Converts shape drawn with interactive pen into basic shape.
B	Multicolor Pen	Draws two-color lines.

Tool	Name	Description
**	Picture Pen	Draws quick shapes or images in a line or pattern as drawn.
	Create Image Page	Adds page with background image, such as music staffs and graphs.
Q	Spotlight	Masks workspace and only displays area inside "spotlight" shape. Click on the Spotlight icon. Use the cursor to drag the Spotlight. When done, click on the Close Spotlight button at the bottom of the screen. The spotlight properties bar has resize handles, gives a menu option for shapes, transparency and window color, and closes the tool.
æ	Link History	Link History is an account of the GWB links. It maintains a record of back links, allowing a click to follow the history of the links and go back to any one of the links during the current session. This tool is available only when a presentation file is open in the Annotation Window and a GWB link has been executed.
R	Zoom	Enlarges a portion of a Workspace page for viewing details.
	Create Duplicate Page	Duplicates current page into new page.
	Create Calendar Page	Selects date and layout for new calendar page.
	Create Gradient Page	Adds a gradient page to the presentation file.
Ø	Flash Player	Imports an interactive Flash (.swf) file into Workspace.
<u>ର</u>	Audio File	Imports an audio file and virtual player into Workspace.
	Video File	Imports a video file and virtual player into Workspace.
	Export PDF File	Exports Workspace lesson to Portable Document Format.
₫.	Email PDF File	Exports Workspace lesson to PDF and opens default email client.
**	Pan Page	Moves a page up, down, left and right when larger than viewable screen.
iiiiii	Onscreen Keyboard	Opens virtual keyboard on screen.
	Lock Pads	Locks all wireless pads connected to Workspace except the Master pad.
	Start Internet Browser	Opens default Web browser.
4	Page Up	Moves to page above.
♣	Page Down	Moves to page below.
	Insert Media	Imports audio, video, or image files into Workspace.
22	Device Manager	Opens window to connect or disconnect whiteboard, panel or wireless pads.
8	Redo	Reapplies a change that was recently "undone."

Tool	Name	Description
*	Preferences	Opens Workspace preferences window.
To T	Text Recognition	Opens window for freehand text recognition.
	Timer	Puts a timer on the screen for timed activities. Click on the Timer icon Set the timer to timer or stopwatch. Click on the Set Timer drop-down arrow to select the length of time. Click on Start to begin.